

ATIS ★ 118.8
CLNC DEL
126.4
GND CON
121.9 361.4
VICTORIA TOWER ★
119.7 239.6
CTAF
119.7
VICTORIA DEP CON
133.85 308.4



VANCOUVER
115.9 YVR
Chan 106
N49°04.64'
W123°08.96'
L-2, H-1

VICTORIA
113.7 YYJ
Chan 84
N48°43.63'
W123°29.01'

CHART NOT TO SCALE



Rwy 13 departures require visual climb to 500.

EMERG SAFE ALT 100 NM 12,800

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RUNWAYS 02, 09, and 13: Track runway heading or as assigned for RADAR vectors. Climb and maintain 3000 or as assigned. Contact Victoria Terminal after passing 1000 unless instructed otherwise by ATC. Expect clearance to flight planned altitude/flight level 10 minutes after departure.